

Turtledeck Top
(make 1)

Inlet spacer
(make 2 from
3 mm Depron)


Canopy
(make 12 with 6 mm Depron
(14 if BlueCore) and
laminate together)

Inside of canopy can be
ed out if airplane CG is not
already too far aft

Missile rails (make 2 from 1/4" x 5/16" balsa)


Vertical tail radar fairing
(make 2 from 3mm Depron)

Cut slot for vertical tail




Aft Fuselage Top
(make 1)


Inboard inlet sides
(make 2 from 3mm
Depron)




Template for rudder pushrod end
(make 1 from 1/32" music wire)




Elevon and rudder control horns
(make 3 from 1/32" plywood)



Aft wing fairing
(make 2)




Bulkhead F-1
(make 1)




Fwd fuselage top
inside (make 1)

Bulkhead F-2
(make 1)





Fwd fuselage
top outside
(make 1)


Nosecone
(make 12 with 6 mm Depron
(14 if BlueCore) and
laminate together)



Nosecone top view template
(trace outline on top of nosecone
to assist in carving it to shape)








s (make 2)

Fuselage top spine
(make 2 and laminate)



1/2" wide foam strip




1/2" wide foam strip


JAS 39 Gripen Park Jet

Designed by Steve Shumate

Copyright © 2004 All Rights Reserved



All parts made from 6 mm Depron or
BlueCore foam unless otherwise specified



77% SCALED VERSION